



WHEN AUXILIARY BATTERY IS FITTED YOU MUST FIT A SPLIT CHARGER

WIRES MUST BE CONNECTED WHEN AUXILIARY BATTERY IS FITTED

COLOUR		CODE	
BL	BLACK	R	RED
G	GREEN	W	WHITE
BR	BROWN	B	BLUE
W/B	WHITE/BLUE	GR	GREY
G/Y	GREEN/YELLOW	W/BL	WHITE/BLACK
T/C W	TWIN CORE WHITE		
T/C R	TWIN CORE RED		
T/C BL	TWIN CORE BLACK		

WIRING DIAGRAM VW VILLA Mk 3